

Model: EZ902 White		Key Definition		Date: March 5, 2007
Key	Action (PC / Media)	PC Keycode	Media Keycode	Note
TrackBall	All Mouse Actions	All Mouse Actions	All Mouse Actions	
TrackBall Click	Mouse Left Click	Mouse Left Click	Mouse Left Click	
L	Mouse Left Click	Mouse Left Click	Mouse Left Click	
R	Mouse Right Click	Mouse Right Click	Mouse Right Click	
Power	Standby PC	System Sleep (0x82)	System Sleep (0x82)	
PC	Change to PC Mode	Ctrl+Alt+[Ctrl+Alt+[
Media	Change to Media Mode	Ctrl+Alt+]	Ctrl+Alt+]	
Laser	Push and Hold for LD On	No	No	
Menu	Menu	Alt+F	Alt+F	
Task-Mgr	Ctrl+Alt+Del / Help	Ctrl+Alt+Del	F1	
Show	Slide Show / Full Screen	F5	Alt+Enter	
Web	Bring Up Web Browser / Mute	WWW Home	F8	
Open	Open File / Play	Ctrl+O (Open)	Ctrl+P	
New	New File / Pause	Ctrl+N (New)	Ctrl+N	
Print	Print File / Stop	Ctrl+P (Print)	Ctrl+S	
Save	Save File / Rec	Ctrl+S (Save)	Ctrl+O	
Home	Home / Rewind	Home	Ctrl+Shift+B	
End	End / Forward	End	Ctrl+Shift+F	
Ch+	Line Up / Channel Up	Line Up	Ctrl+Shift+G	
Vol+	Line Right / Volume Up	Line Right	F10	
PgUp	Page Up / Previous Track	PageUp	Ctrl+B	
PgDn	Page Down / Next Track	PageDn	Ctrl+F	
Ch-	Line Down / Channel Down	Line Down	Ctrl+Shift+S	
Vol-	Line Left / Volume Down	Line Left	F9	
ESC	Esc	Esc	Esc	
TAB	Tab	Tab	Tab	
Enter	Enter	Enter (13)	Enter (13)	
Bkspace	Backspace	Backspace	Backspace	
INS	Insert	Insert	Insert	
DEL	Delete	Delete	Delete	
1	Number 1	1	1	
2	Number 2	2	2	
3	Number 3	3	3	
4	Number 4	4	4	
5	Number 5	5	5	
6	Number 6	6	6	
7	Number 7	7	7	
8	Number 8	8	8	
9	Number 9	9	9	
Mode	* key	Shift+8	shift+8	
0	Number 0	0	0	
Space	Space / # key	<space>	shift+3	